

SONIQ HQ PLUS

SITE READINESS DOCUMENT



Prerequisites for SONIQ HQ PLUS:

Contents

- 1. Power Supply
- 2. Computer Requirements
- 3. Environment Requirements
- 4. Floor & Space

Power Supply

- Total Power Consumption is 3.2KW
- Uninterrupted Power supply of 220V, 20 Amps (+ / 10%), 50Hz
- Exclusive Earthing: It should not be shared with UPS and Building's common Earthing
- Printer and computer must share same exclusive Earthing

Computer Requirements

- **Processor**: i9 processor
- **RAM**: 8GB RAM or more
- **Operating System:** Windows 10
- Human Input Devices: Keyboard and Mouse
- HDD/SSD: 500GB or more
- USB: USB 2.0 Port or more
- Color monitor with 1600x1024 resolution 24-bit

Note: If computer system configuration doesn't meet the above-mentioned specifications, then printer performance gets slow down (will affect the printing data transfer).

Environment Requirements

Room temperature should be maintained in the range of 24 ° C <u>+</u> 4 with humidity 73% <u>+</u>10% RH.

Please note: Printer is equipped with dryer heater, it may raise the room temperature 10% additional load should be considered when designing the AC.


- There should not be air draught in the room
- Closed dust-free room exclusive for Printer



Floor & Space

- Net Weight: 550 Kgs
- Gross Weight: 742 KGS
- Machine Dimension (L x W x H): 4525x 885 x 1500 MM
- Packing Dimension of Long Pallet (L x W x H): 4590 x 910 x 874 MM (Machine Upper Body)
- Packing Dimension of Cabinets Small Pallet (L x W x H): 1285 x 790 x 1254 MM (Side Cabinets)
- Room Dimensions (L x W x H): 6525 x 2885 x 3000 MM

SONIQ HQ PLUS Site Layout: Top View



SONIQ HQ PLUS Site Layout: Height of the machine

